


















Coral



	CUCHARA MESA TABLE SPOON	11054001	201 mm.
	TENEDOR MESA TABLE FORK	11054002	199 mm.
	CUCHILLO MESA TABLE KNIFE	11054003	214 mm.
	CUCHARA POSTRE DESSERT SPOON	11054004	181 mm.
	TENEDOR POSTRE DESSERT FORK	11054005	179 mm.
	CUCHILLO POSTRE DESSERT KNIFE	11054006	195 mm.
	CUCHARA CAFÉ TEA SPOON	11054007	144 mm.
	TENEDOR LUNCH CAKE FORK	11054008	146 mm.
	CUCHILLO LUNCH FRUIT KNIFE	11054009	182 mm.
	PALA PESCADO FISH KNIFE	11054010	199 mm.
	TENEDOR PESCADO FISH FORK	11054011	179 mm.
	CUCHARA MOKA MOKA SPOON	11054012	115 mm.
	CAZO SOPA SOUP LADLE	11054015	300 mm.
	CUCHARÓN SERVIR SERVING SPOON	11054016	252 mm.
	TENEDOR SERVIR SERVING FORK	11054017	252 mm.
	PALA TARTA CAKE SERVER	11054021	246 mm.
	CACILLO AZÚCAR SUGAR SPOON	11054022	139 mm.